

## Converting and Transferring MP4 Video Files to the WowBible Color

- All desired Video files for use on the WowBible Color must first be converted to .MP4 format. The MP4 Tool that comes pre-loaded on the WowBible Color is capable of converting many common Video formats including: .WMV and .MOV files.
- Most DVD videos must first be converted to .WMV or .MOV first, and then converted again by the MP4 Tool.
- All video files must be converted using the MP4 Tool, including video files that already have a .MP4 file extension or format.

(\*\*\*Note: The MP4 Tool does not support video conversion of DVDs. This type of conversion will require more advanced Video Conversion software that is not available from the WowBible company at this time.)

### **Step 1: Connecting the WowBible to your Computer in “Udisk Mode”**

\*\*\*The MP4 Video Conversion tool is located on your WowBible Color’s internal memory, therefore it is necessary to connect the WowBible to your computer to install the MP4 Software Tool for the first time.

\*\*\*Note: It is recommended to disconnect all removable devices (such as Flash Cards, Memory Sticks, Digital Cameras, etc..) before connecting the WowBible or entering “Udisk Mode”.

First, Power off your WowBible if it’s not already off.

With the WowBible “Off”, Connect the device to your computer using the USB Cable provided.

After you connect to the computer, the WowBible Screen will temporarily show the word “**Initializing**”.

The WowBible screen will now show the options “**System**” or “**USB Disc Mode**”

Select “**USB Disc Mode**” (the option on the right)

The WowBible screen will now say “USB Disk Mode, Stop USB disk Mode before disconnection!” and you will hear a sound if your computer speakers are turned on.

If your system does not automatically open the device, click on the Start Menu at the bottom left corner of your screen:



Select **“My Computer”** from the Start Menu:




If you cannot access **“My Computer”** from the Start Menu, or if your start menu looks different than the image above, try accessing it from your desktop:



Access the **“My Computer”** folder by double-clicking the appropriate icon.

## Step 2: Open the WowBible Folders through “My Computer”

Depending on how many removable devices are connected to your computer through USB ports, you may see multiple devices in this folder:




On the example above “**Removable Disk (G:)**” is the **WowBible Color**, while “**Removable Disk (H:)**” is the **Micro-SD card slot**. Even if an SD card is not inserted into the slot, the computer will recognize that potential memory. If an SD card was inserted in the slot, this is how you could access the card’s memory.

(\*\*\*Please Note: These Drives may have different letters depending on which USB port is occupied on your computer)

To access the WowBible folders, **Double-Click** on the appropriate Removable Disk icon (Removable Disk (G:) for the WowBible in the example above).


You should see the following WowBible folders:



Double-Click on the “MP4 Converter” folder to open it.


### **Step 3: Install the MP4 Tool Software**

You should now see the following in the “**MP4 Converter**” folder:




Double-Click on the “**MP4Tool-305E**” icon to begin installing the software.


The Setup Wizard will begin and should look like this:




Click “Next”.




Click “I Agree”.



Click **“Install”**.




The software will begin installing and the progress meter will look like this.




Once the Setup Wizard is complete, Click “**Finish**” as indicated on the image above.

The MP4 Tool should automatically open and will look like this:



#### **Step 4: Use the MP4 Tool to convert Video files for use on the WowBible**

First, Click on “**File**”. Then Click on “**Open Source**” from the File Menu that appears. The new window will look like this:




Second, locate the video files on your hard drive that you would like to convert to .MP4.

(\*\*\*Note: Many Windows based PCs will have videos located in the “**My Videos**” folder such as on the example above. If you do not have a “My Videos” folder on your computer, access a different folder that does contain video files by clicking on the “**Look in:**” menu at the top of this window.)


Double-Click on the icon of the desired Video File that you would like to convert. (Such as “WowBible Sample Video” from the example above)

This will take you back to the Main Screen of the MP4 Tool.

Third, Click on “**File**”. Then Click on “**Select Target**” from the File Menu that appears. The new window will look like this:



The “**Select Target**” command allows you to specify where you want the converted .MP4 video file to be saved. If you would like to select a different folder than the default “Open Source” folder that appears, click on the “**Look in:**” menu at the top of this window that will look like this:





After you have selected the “Target” folder for your converted video file, this will take you back to the Main Screen of the MP4 Tool.

**\*\*\*PLEASE NOTE: it is recommended to save a backup copy of all converted video files on your computer hard drive.**


**Recommended Example:** Create a folder within “My Videos” or “My Documents” called “WowBible MP4 Videos”. Use this new folder to store all backup files of converted MP4 Videos ONLY.

To create this folder, Click “Make a new folder”:






Change the name from “**New Folder**” to “**WowBible MP4 Videos**”:



”**WowBible MP4 Videos**” will now be the specified folder for the “**Select Target**” command.


Now that the desired Video file for conversion has been selected (via the “**Open Source**” command) and the desired folder has been selected for saving the converted file (via the “**Select Target**” command) the file is ready to be converted.

Fourth, Click the “**Convert**” button:




The video file will begin converting to .MP4 format.

The conversion progress and the estimated conversion time will be displayed such as the example below:



Once the file has been fully converted, the following popup window will appear:



This means that the converted MP4 Video File should now be saved in your “**WowBible MP4 Videos**” folder that was created in the THIRD step above.


### **Step 5: Copy and Paste video files from the “Select Target” folder to the WowBible “Movie” Folder**

Now that the desired video file has been converted using the MP4 Tool and is located in the “**WowBible MP4 Videos**” folder, it is necessary to Copy and Paste to the WowBible “Movie” folder.


First, locate the converted video files in your “**WowBible MP4 Videos**” folder.  
Do this by clicking “**Start**”:




Click “**My Documents**”:




Double-Click “My Videos”:




Double-Click “WowBible MP4 Videos”:



On the example below, to add the “**WowBible Sample Clip**” (or any video file that was converted using the MP4 Tool) to the WowBible, first **Right-Click** on the appropriate file name, then **Left-Click** the word “**Copy**” from the vertical menu that appears:




Once the Video file has been copied, go back to the “**MOVIE**” folder of the WowBible:



(Remember, to do this Click “**Start**”, “**My Computer**”, “**Removable Disk: G**”, then “**Movie**”)

**Right-Click** on the **white background** of the WowBible’s “**MOVIE**” folder, then **Left-Click** the word “**Paste**” from the vertical menu that appears. This will add the selected file to the WowBible:



Repeat this same process with any other desired MP4 Video files, beginning with Step 4 from above (as the MP4 Software Tool should now be installed).

\*\*\*Note: It is also possible to Copy and Paste entire folders or multiple converted Video files at once into the WowBible “Movie” folder. Doing so will allow you to maintain the same Folder Names and navigational structure of the video files on your computer.

## **Step 6: Safely Remove the WowBible from your Computer**

Once all desired MP4 Video files are added, it is now necessary to “**Safely Remove**” the WowBible from your computer.

Before disconnecting the WowBible from the USB cable, **Left-Click** on the “**Safely Remove Hardware**” icon at the Bottom Right corner of your screen (next to the clock):



The “**Safely Remove Hardware**” icon is the **Green Left-Pointing Arrow hovering over a Grey Disk**.



(When the pointer is hovering over the correct icon, the words “**Safely Remove Hardware**” will appear.)

**Left-Click** the “**Safely Remove Hardware**” icon.

Then **Left-Click** on “**Safely Remove USB Mass Storage Device – Drives (G:, H:)**”

(\*\*\*Please Note: These Drives may have different letters depending on which USB port is occupied on your computer)

After doing so, a popup message will appear saying “**Mass Storage Device can now be safely removed**”, and the **WowBible screen will now go to the Main Menu**.

From the Main Menu of the WowBible screen, tap the “**MOVIE**” icon to test and play the video files that were added.

**Congratulations! You can now view portable videos anywhere that you take the WowBible!**